

LV 20 PART LIST BREAKDOWN

NRP PART NUMBER

DESCRIPTION

1	B03001	Pneumatic Pump
2	B03002	Fan Motor
3	G03005	Air Regulator (Pump)
4	B03004	Air Regulator (Fan)
5	G03004	Air Filter
6	B03006	High Side Gauge
7	B03007	Low Side Gauge
8	B03008	3/8 Check Valve
9	B03009	Mini Lubricator
10	B03010	1/2" 3-Way Valve
11	B03012	3/8 Ball Valve
12	B03017	12" Fan Blade
13	B03018	Fan Guard
14	B03019	Condenser Coil
15	B03020	3/8" Fan Hub
16	B03021	3/8" Strainer
17	B04003	3 Way Valve Brace
18	B04006	Coil Shroud
19	B04009	End Cap
20	B04010	Extension
21	F03001	LV20 Cart
22	F03005	1/2" Ball Valve
23	G03006	Air Regulator Gauge
24	T15-004	Vibration Eliminator
25	R06011	9" Wheel for Cart Assembly