


LV20 Part List Breakdown



<u>Number</u>	<u>NRP Part Number</u>	<u>Description</u>
1	B03018	Fan Guard
2	B04006P	Coil Casing
3	B04003	Hand Truck
4	B03007	Refrigerant Gauge - Marked 30" - 0 - 300psi
5	F03005	1/2" Ball Valve
6	B03001	Pneumatic Pump
7		Purge Inlet Hose
8	G03006	Regulator Gauge
9	G03004	Air Filter
10	B03010	1/2" 3-Way Valve
11		Suction Hose
12	B03006	Refrigerant Gauge - Marked 0-600psi
13	B03012	3/8" Ball Valve
14		} Condenser Inlet Hose
15	T15-004	
16	B03019	Condenser Coil
17	G03005	Air Motor Regulator
18	B03009	Fan Mini Lubricator
19	B03002	Fan Motor