

SPARE PARTS LIST	LV8
------------------	-----

1	5421	Fan Motor
2	A03001	Condenser Coil
3	A03002	Fan Guard
4	A03003	Booster Pump
5	A03004	Fan Blade
6	A05008	Condenser Outlet Hose
7	A07001	Air Compressor
8	B03003	Air Regulator
9	B03005	Air Filter
10	B03007	Refrigerant Gauge 0-600 PSI
11	B03007	Refrigerant Gauge 0-300 PSI
12	B03008	Check Valve
13	B03010	1/2" 3-Way Valve
14	B03016	Suction Line Hose
15	B03016	Air Inlet Hose
16	F03001	Hand Cart
17	F03005	1/2" 2-Way Valve
18	G03007	Condenser Inlet Hose