

2. PUMP COMPONENTS / PARTS LIST



	Part Name	Part Number by Model		
		GVP3	GVP6	GVP12
1	Handle	VP3H	VPZ6H	VPZ6H
2	Gas Ballast Valve	VPZGB	VPZGB	VPZGB
3	Oil Tank with Sight glass	VP3RES	VPZ6OT	VPZ12OT
4	Oil Drain Plug	VPZ6ODP	VPZ6ODP	VPZ6ODP
5	Base	VP3BP	VPZ6BASE	VPZ12BASE
6	Motor	VP3MTR	VPZ6MTR	VPZ12M
7	Valve with Caps	VPZ6VK	VPZ6VK	VPZ6VK
8	Oil / Exhaust Cap with o-ring	VPZ6OC	VPZ6OC	VPZ6OC
9	Power cord 110V (not shown)	UPC110V	UPC110V	UPC110V